

**STEP 13**

**STEP 14**

**STEP 15**

5

Popisky / Stencils

**Airacobra I / P-400**  
Americký stíhací letoun / American WW II fighter

6

# P-400 Airacobra

Americký stíhací letoun / American WW II fighter

The Airacobra entered first service with the RAF in October 1941. Only one RAF squadron ever received the Airacobra. No.601 "City of London" The Airacobra's brief RAF combat career lasted from 9-11 October 1941. No.601 Squadron sent its four airworthy aircraft on two fighter sweeps to France. Only eighty of the British Airacobras were assembled for the RAF. Of the remaining aircraft around 200 were quickly dispatched to the Soviet Union while the rest remained in the United States, and as the P-400 fought on New Guinea and Guadalcanal.

**92133**

Stavební návod / Instruction

**LEGEND**

- ohnout / bend
- vlečtinové lepidlo / cyanoacrylate glue
- odstranit / remove
- upravit / reduce
- vrtat / open hole
- vyrobit / scotch build
- obtlisk / decal
- barva / color
- film

**COLORS**

a	Černá / Black	h	Červená / Red
b	Interier. žlutá / Yellow primer	i	Bílá / White
c	Stříbrná / Silver	j	Žlutá / Yellow
d	Přítko / Linen	k	Pneumatiky / Tyres Black
e	Kůže / Leather	l	Rezavá / Rust
f	Hliníková / Aluminium	m	Tmavě šedá / Dark Gray
g	Chromová / Chrome	n	Kovová / Gun metal
p	Olivová / Olive	o	Inter. zelená / Zinc Chromate green

1

92133

