



GERMAN U-BOAT
Item No. MMS121

To create the best connections

- Insert tab and bend 90 degrees for most visible areas
- Insert tab and twist 90 degrees is best in some areas to ensure a tight connection

Needle nose pliers are helpful for assembly

Legends:

- Engraved side
- Non-engraved side
- Attention point

Insertion tabs are inserted and then folded

Fold lines can be seen as shown here

Insertion holes

Pull and Screw metal tab 90° to tighten

Metal sheets

In order to avoid possible injury from sharp edges, please carefully discard the metal sheet after parts have been removed

Assembly Flow Chart



